

SPYRABASE HURRICANE GROUND ANCHORS

- 1. ENSURE THAT THERE ARE NO UNDERGROUND SERVICES WHERE THE PRODUCT IS TO BE USED.**
- 2. HOLD THE PRODUCT AT 90 DEGREE TO THE GROUND, PUSH THE POINT INTO THE GROUND, KEEPING A CONSTANT DOWNWARD PRESSURE UNTIL THE ANCHOR HAS GOT A BIT INTO THE GROUND.**
- 3. USING THE MANUAL DRIVER OR TURNING BAR, ROTATE THE PRODUCT CLOCKWISE INTO THE GROUND.**
- 4. ROTATE UNTIL THE TOP PLATE IS FLUSH WITH THE GROUND.**
- 5. DO NOT PUT THE ANCHOR HALF WAY INTO THE GROUND AND PUT A CHAIN AROUND IT, AS THIS WILL CAUSE DAMAGE TO THE ANCHOR AND WILL NOT HOLD TO THE RATED HOLDING POWER.**
- 6. ONLY TO BE INSERTED MANUALLY OR WITH THE H.S.S. HIRE SHOPS HYDRAULIC POST HOLE BORER.**
- 7. NOT TO BE USED WITH POST DRIVER OR IMPACT DRIVERS.**